

## Timer Instructions

- 1) Insert battery (recommend replacing AA battery every year with a alkaline Battery) **DO NOT USE RECHARGEABLE BATTERIES**
  
- 2) Set Time:  
    Hold the **SET** button until display blinks  
    Press **HOURL** until correct hour is displayed  
    Press **MIN** until correct Minutes are displayed
  
- 3) Repeat step #2 for setting feed cycles 1-6

While in program mode for feed cycles, you can change the minimum 3-second run time by pressing the **runtime** button. Once in the runtime setting, press the **seconds** button until desired feed time is displayed.

**\*\* You will not see the word OFF when the timer is not active.**

If you want to **turn off** any feed cycle 1-6, enter the program mode, **make no changes**, and exit the program mode. That feed cycle will no longer be on.

\*The test button has a 4 second delay and will run for 10 seconds no matter what run time you have set.

After you program feed cycles 1-6, and exit to the main time display, everything you programmed will be set. If you scroll back through modes 1-6 you will see the word ON displayed in all feed cycles 1-6. If you want to check the feed cycles you have not programmed to make sure they are not active, you do nothing more than enter a mode that has not been programmed, press the run time key twice, and the word ON will no longer be displayed.

**\*\*\*If you want to feed three times a day, program feed cycles 4,5,6, If you want to feed twice a day program feed cycles 5, 6, and the word ON will not be displayed in the lower feed cycles that are not programmed.**

**\*\*\*NOTE:**

**When not in a program mode, pressing the HOUR key will switch the time from standard time to military time. Pressing the HOUR key again will change it back from military time to standard time.**